www.coretechortho.com

coretech® by vivehealth

OWNER'S MANUAL
386 WALKER BOOT TALL

SKU: SUP3092BLKT



To see all FAQs in one place, visit, **coretechortho.link/gvw**

SUP3092BLKT

386 WALKER BOOT TALL

PUTTING THE WALKER ON

For a video demonstration,
check out **coretechortho.link/f0o**

1. Unfasten all straps and remove the soft padded liner.



2. Remove the two hook and loop strap protectors from the inside, pull up and discard. This will allow the liner to secure into place.



3. Place the padded liner back into the walker and insert your foot.



4. (Optional) Two extra pads are included to cushion the inside of the liner,



they can be used around the ankle, the calf, under the foot, or the straps.



5. Secure the bottom strap, then the top.



Make sure your heel is positioned completely back.



6. Secure the outer straps from bottom to top and tighten to a comfortable fit.



Do NOT overtighten.



CARE

- Remove the padded liner. Hand wash in cold water with a mild detergent. Air dry.
- Wipe the walker with a damp cloth and dry immediately.
- Do NOT machine wash or dry.

www.coretechortho.com

coretech®

by vivehealth

Distributed by

vivehealth

8955 Fontana Del Sol Way
Naples, FL 34109
1-800-487-3808
www.vivehealth.com

021124